



Taper Roller Bearing Fitting Instructions



1. Remove the old outer races from the frame and the old inner cones from the yoke.
2. Fit your new outer races to the frame using a suitable drift (block of wood) and a hammer
3. Fit the lower cone with the large inner hole to the lower yoke
4. Re-assemble the yokes and forks as per workshop manual, ensuring plenty of grease is used

Call British Cycle Supply for other fine SRM products!

(902)542-7478

www.britcycle.com