

TELEPHONE

e-mail:

(902)542-7478 902)542-7479

info@britcycle.com

www.britcycle.com

& 50 CONNECTICUT ROAD, LORING COMMERCE CENTER, LIMESTONE, MAINE, 04750, USA 604 DAVISON STREET, RR3 WOLFVILLE, NOVA SCOTIA, B4P 2R3, CANADA

WORK TO DIMENSIONS, DO NOT SCALE. UNTOLERANCED DIMENSIONS +/- 0.0050"

shocker length, weight of bike, alloy engine plates etc all make a difference and for the time being we are going to supply these unpainted and would recommend that you do a dry run when roughly adjacent to the large sump plug, taking the center line of the sump plug the pivot pin on the stand is roughly 1/.2" to 1" rearwards, first thing to adjust is the lean angle then go from another three on bikes. Not one was the same, the 54 wideline has a very spindly looking stand, the 650ss a sturdier looking job, both original, the 650 stand hit the exhaust pipe, the Manxman examples generally available. We are trying to make a better product but I have had some difficulty in establishing the relevant dimensions. I sorted out all my samples, a total of three, plus fitting, and adjust as necessary prior to painting. If you have not fitted a stand before note you will really need to dismantle the entire primary and remove the inner cover, stand is positioned has a rather clumsy looking reproduction item, this hit the frame. Setting the angles on the stand is quite easy, but the optimum position for each application seems to vary slightly, rim size, Thankyou for your order, please find your side stand enclosed, we have been working on these for some years now, and this is a new batch, using proper forgings for the leg rather than the cast

