



ATTACHING SCREEN TO FAIRING:

1. PLACE SCREEN ON FAIRING BODY, THEN ATTACH WITH SCREW, WASHER & NUT, DO NOT TIGHTEN. AFTER ALL POINTS ARE ATTACHED, SLOWLY TIGHTEN ALL MOUNTING SCREWS UNTIL FLUSH.

DO NOT OVER TIGHTEN

ATTACHING FAIRING TO MOTORCYCLE:

1. ATTACH HEADLIGHT BRACKETS TO FAIRING. **(A)**
2. LOOSEN HEADLIGHT BOLTS. **(B)**
3. SLIP FAIRING HEADLIGHT BRACKETS INTO HEADLIGHT SIDE BOLTS.
4. TIGHTEN ALL MOUNTING POINTS UNTIL FAIRING IS FLUSH AT ALL POINTS, ADJUST AS NECESSARY.
5. TIGHTEN ALL NUTS AND SCREWS.
6. RIDE MOTORCYCLE FOR A SHORT RIDE, AND RECHECK ALL NUTS AND SCREWS TO MAKE SURE ARE ALL SECURE.