



FAX:
e-mail:
website:

(902)542-7479
info@britcycle.com
www.britcycle.com

604 DAVISON STREET, RR3 WOLFVILLE, NOVA SCOTIA, B4P 2R3, CANADA (902)542-7478
& 146 PORTER STREET, HACKENSACK, NEW JERSEY, 07601, USA (201)880-0366

321-06

Headlight Bracket Assembly Instructions

- 1) Two screws, opposing ends secure the clamp to the fork tube while locating the ear.
- 2) The center screw locks the ear.
- 3) The clamp is 35mm I.D.
- 4) The black shim stock is for Triumph and BSA fork tubes 1971 on. The brown shim stock is for Norton fork tubes.
- 5) Install shim stock with the opening toward the headlight ear.



IMPORTERS AND DISTRIBUTORS OF PARTS AND ACCESSORIES
FOR CLASSIC TRIUMPH, BSA AND NORTON MOTORCYCLES
HELPING TO KEEP BRITISH MOTORCYCLES ON THE ROAD SINCE 1977!
