

The T160 parts needed for mounting the starter to an R3 or T150 are:

- 57-4667 – COVER, CLUTCH ASSEMBLY, 3 CYL (INCLUDING 57-3642 SEAL AND 57-3756 OIL TANK ADAPTER)
- 57-4874 – COVER, BREATHER DUCT, 3 CYL (my breather cover moves the breather tube back to the original position)
- 57-4678 – RING GEAR, STARTER, T160
- 57-4677 – CLUTCH BASKET

In addition an automotive relay (12V, 20A), handlebar switch, battery cables and 10AHr or greater battery.

The first picture shows the outline of the Lucas starter intermediate housing on the clutch housing when bolted to a T150. The second picture shows where the gearbox flange has to be trimmed. The left and centre float bowl drains touch the starter. They can be changed to the early bowls without drains or the carb gantry can be lifted slightly with a tie wrap around the backbone and middle gantry spickot.



